

SIRENIX AUTO-FILL DRILLING TEMPLATE

Instructions

1. Print at 100% scale (8.5" x 11")
 2. Cut out along dotted outline
 3. Align the flat edge of this template flush with the outer rim of the Sirenix basin.
 4. Mark the drill center through the guide hole shown below.
 5. Drill straight through the top panel with a 5/8" bit.
 6. Clean edges before inserting float valve.
-

CAUTION:

- Do **not over tighten** float valve.
 - Do **not drill** when the basin contains water or is wet.
 - Always wear **eye protection** when drilling plastic materials.
-

For pre-drilled 2025+ units, this template is not required.

SIRENIX RETROFIT AUTOFILL HOLE TEMPLATE

